RBVS

Universal Ball Valve/Solenoid Coil Supervisory Switch

Application

The Model RBVS is designed to monitor the fully open or closed position of a ball valve installed in a sprinkler system as well as monitor the position of a coil on a solenoid for a preaction/deluge system.

Details

Part #.....Universal Ball Valve/Solenoid Coil Switch: 1000065
Cover tamper Kit (Optional): 0090224

Listings..... UL Listed & FM Approved

Selling Features

- Includes mounting hardware to supervise coils on most solenoids
- Assembled in USA
- Fits most lever/tee type ball valves up to 2”
- Fits most backflow preventers up to 2”
- Operates on open or closed valves
- Accommodates up to 12 AWG wire
- Optional field installed cover tamper switch kit (0090224)
- RoHS compliant

Code Requirements

Can now be used to satisfy NFPA 13-2019 requirement for Actuator Supervision (8.3.1.2.1)*.

Common Questions

Q: What type of mounting is included?

A: The unit includes a small “L” bracket and “V” clamp to allow the RBVS to mount directly to the nipple on the coil of a solenoid valve.

Q: Is there a cover tamper switch available?

A: Yes. If an attempt is made to remove the RBVS by the removal of the mounting brackets, the unit will be set into the tripped mode by this action.

*Will go into effect January 1st, 2021.